

Wireless HART **TOXIC & COMBUSTIBLE GAS DETECTOR**





















CAPABILITY OVERVIEW

Wireless Capability

- WirelessHART® communication 7.2
- IEC 62591 compatible
- Integrated HART terminals
- Adjustable update rate

FLEXmount™ Bracket

- Mounting bracket for pipe or wall mount
- Facilitates easy installation and replacement of unit

Heavy Duty Design

- Class I, Div. 1&2 for hazardous areas
- Explosion-proof & intrinsically safe

*FLEX*sense™ Sensor

- Automatically configures toxic or combustible gas sensor for readings in ppm or %LEL
- Sensor is field replaceable in hazardous location areas


Interoperability

 Seamless integration with existing WirelessHART networks and asset management systems

angua

Long Lifespan

- 5 years battery life*
- Battery pack is field replaceable in hazardous location areas



- Configure, calibrate, and test onsite with the touch of a button
- showing gas concentration, network connection, and battery status

WirelessHART® is a registered trademark of Field Comm Group. FLEXsense™ is a trademark of United Electric Controls Co.

^{*}Based on an 8 second update rate. 5 years battery warranty valid upon battery warranty registration.





SPECIFICATIONS

Sensor

| | Methane (CH ₄) | Hydrogen Sulfide (H ₂ S) | Carbon Monoxide (CO) |
|------------------------------------|--|---|---|
| Storage Temperature: | 72°F (22°C) recommended | | |
| Storage Life: | 3 years in sealed package | 1 year in sealed package | 6 months in sealed package |
| Expected Operational Life 1: | 5 Years | 2 Years | 2 Years |
| Operating Temperature: | -40°F (-40°C) to 149°F (65°C) | -40°F (-40°C) to 149°F (65°C) | -40°F (-40°C) to 131°F (55°C) |
| Types: | Nondispersive infrared | Electrochemical | Electrochemical |
| Measurement Range: | 0 to 100 %LEL | 0 to 100 ppm | 0 to 500 ppm |
| Resolution: | 1% LEL | 1 ppm | 1 ppm |
| Accuracy ² : | \pm 2% LEL or \pm 5% of indication, whichever is greater | \pm 2 ppm or \pm 5% of indication, whichever is greater | \pm 5 ppm or \pm 5% of indication, whichever is greater |
| Response Time (T90) ³ : | 30 Seconds | <30 Seconds | <30 Seconds |
| Stabilization Time: | 2 Minutes | <1 Minute | <1 Minute |

Note: Sensors are interchangeable & self-configurable with the transmitter base. Sensor allows for one-handed sensor installation in hazardous area without declassifying the area

Battery

Batteries: Battery pack contains two Lithium battery cells

Operating Voltage: 7.2 V

Life: 5 years based on an 8 second update rate

¹Expected operational life varies with environmental conditions and gas exposure

²At standard conditions: 68°F (20°C) and 1.0 atm. Accuracy may vary with frequency, accuracy of calibration, and environmental conditions (e.g., barometric pressure, temperature and humidity).

³Excludes latency due to radio burst rate.



SPECIFICATIONS CONT.

Base Transmitter

Operating Temperature: -40°F (-40°C) to 149°F (65°C)
Operating Humidity: 0% to 98% RH recommended

Material: Aluminum alloy (maximum copper content at 0.25%) with powder polyester paint;

316 stainless steel; nickel-plated brass; tempered glass

Ingress Protection: Type 4X (enclosure only)

Display: Viewable area is 2.25"W x1.25"H (57.2mm x 31.8mm)

Graphical LCD display

Display Language: English

Memory: Programming and data are protected by a non-volatile EEPROM

Antenna: 2.4 GHz, Hazardous Area Antenna

Mounting: FLEX mount ™ Options

Weight: 7.84 lbs (Base)

9.61 lbs (Base with Sensor and Battery)

Output and Access

Communication Protocol:

WirelessHART® HART 7.2; EDDL file available at www.ueonline.com/vanguard

Process Variables:

Primary Variable (PV): Methane (CH₄) concentration in %LEL

Hydrogen Sulfide (H₂S) concentration in ppm Carbon Monoxide (CO) concentration in ppm

Secondary Variable (SV): Temperature (°C); Not available for Methane sensor

Tertiary Variable (TV): Days since calibration (days)
Quaternary Variable(QV): Battery voltage (volts)

Programming Access: Vanguard Configurator, HART hand-held communicator, or via HART modem,

connected to HART terminals located in rear battery compartment or via remote

access (e.g., asset management software)

Calibration/Bump Test

Access:

Via external button on transmitter base





HOW TO ORDER

Product Part Number Example:

Vanguard with Standard Mount and Methane Sensor is TCD50H1A03

FLEXmount™ FLEXsense™ Option Option

TCD50H1

Α

03

ORDERING

CODE DESCRIPTION

VANGUARD GAS DETECTOR DESIGNATION

TCD50H1 Base Transmitter; includes enclosure, operating system,

radio module WirelessHART 7.2 communication

protocol, and a 2.4 GHz antenna

STEP 1 - CHOOSE FLEXmount™ OPTION

A Standard Mount
B Magnetic Mount
C Universal Mount

STEP 2 - CHOOSE FLEXsense™ OPTION-

03 Methane Sensor

04 Hydrogen Sulfide Sensor 05 Carbon Monoxide Sensor

N/A No Sensor

STEP 3 - CHOOSE A BATTERY*

6361-807 Battery pack containing two lithium battery cells; 7.2V operating voltage**

STEP 4 - CHOOSE A CALIBRATION KIT*

62169-50 Gas Calibration Kit including Cap and Regulator


ACCESSORIES AND REPLACEMENTS

| 6361-807 | Battery pack containing two lithium battery cells; 7.2V operating voltage** |
|----------|--|
| 62169-50 | Gas calibration kit including calibration cup and regulator |
| 62169-54 | FLEXsense™ Methane (CH ₄) sensor; sensor pack only, excludes base transmitter |
| 62169-53 | FLEXsense™ Hydrogen Sulfide (H ₂ S) sensor; sensor pack only, excludes base transmitter |
| 62169-55 | FLEXsense™ Carbon Monoxide (CO) sensor; sensor pack only, excludes base transmitter |
| 6361-811 | FLEXmount™ Standard Mounting bracket kit |
| 6361-817 | FLEXmount™ Magnetic Mounting bracket kit |
| 6361-818 | FLEXmount™ Universal Mounting bracket kit |


^{*}Ordered as a seperate line item

^{**}Battery ships separately per US and International Transport Authorities (e.g., IATA). Follow proper disposal regulations for lithium batteries as they apply to your jurisdiction.

DIMENSIONAL DRAWINGS




FLEXMOUNT™ BRACKET OPTIONS





DIMENSIONAL DRAWINGS CONT.

CALIBRATION KIT



PRODUCT APPROVALS & RATINGS

| Model | N. America | Europe | International |
|------------|--|---|--|
| TCD50H1XXX | Class I, Division 1, Groups C and D, T4 Class I, Zone 1 AEx db ia [ia] IIB T4 Gb Ex db ia [ia] IIB T4 Gb Type NEMA 4X Enclosure. IP 66 (*Excludes Gas sensor) -40°C ≤ Tamb ≤ +65°C | ITS 16 ATEX 18474 II 2 (2) G Ex db ia [ia] IIB T4 Gb IP66** -40°C ≤ Tamb ≤ +65°C* | IECEx ETL 16.0016 Ex db ia [ia] IIB T4 Gb IP66** -40°C ≤ Tamb ≤ +65°C* |

^{*}Ambient operating temperature range may vary with sensor type.

UE declarations and third-party issued agency certifications are available for download at: www.ueonline.com/prod_approval.

COMPLIANCE TO STANDARDS

The device has been certified in accordance with the applicable requirements of the standards listed on page 5 of the installation and maintenance manual.

^{**}Enclosure Type 4X and/or IP66 rating excludes sensor.



RECOMMENDED PRACTICES AND WARNINGS

United Electric Controls Company recommends careful consideration of the following factors when installing and operating the UE Vanguard unit. Before installing a unit, the Installation and Maintenance instructions provided with the unit must be read and understood.

- This device is for monitoring and communicating gas concentration levels for data collection or record keeping and does not provide alarm signals.
- Misuse of this device may cause explosion and/or personal injury. These
 instructions must be thoroughly read and understood prior to installation of the
 device.
- The end-user is responsible for maintaining the device in full, operational condition.
- Install the device where shock, vibration and temperature fluctuations are minimal.
 Do not mount in ambient temperatures that exceed the limits on the device labelling.
- The device must be mounted vertically with the sensor pointing downward.
- Avoid dropping the device, as loosening of the threaded flame-proof joints or permanent damage may occur.
- When not in use, the device should be stored in a clean, dry area and within the temperature range listed within the device's environmental specifications.
- The only field replaceable parts are the battery pack and FLEXsense™ sensor. Substitution of other components will invalidate third party issued approvals and certifications, may impair suitability for Class 1, Div 1 location and void any warranties.
- Only battery packs and *FLEX*sense™ sensors provided by United Electric Controls are compatible with this device.
- New sensors must be calibrated after installation.
- Hydrogen Sulfide (H₂S) is an extremely toxic gas, and exposure may result in loss of consciousness or death.
- Methane (CH₄) is a greenhouse gas and is extremely flammable. Exposure in closed areas may cause explosion, and result in loss of consciousness or death.

LIMITED WARRANTY

Seller warrants that the product hereby purchased is, upon delivery, free from defects in material and workmanship and that any such product which is found to be defective in such workmanship or material will be repaired or replaced by Seller (Ex-works, Factory, Watertown, Massachusetts. INCOTERMS); provided, however, that this warranty applies only to equipment found to be so defective within a period (as defined in the chart below) from the date of manufacture by the Seller.

| PRODUCT SERIES/COMPONENTS/REPLACEMENT PARTS | WARRANTY |
|---|------------|
| Electrochemical Sensors | 12 months |
| Infrared Sensors | 24 months |
| Vanguard Base Transmitter | 36 months |
| Battery | 60 months* |

^{* 5} year battery warranty valid only with registration at www.ueonline.com/vanguard

Seller shall not be obligated under this warranty for alleged defects which examination discloses are due to tampering, misuse, neglect, improper storage, and in any case where products are disassembled by anyone other than authorized Seller's representatives. EXCEPT FOR THE LIMITED WARRANTY OF REPAIR AND REPLACEMENT STATED ABOVE, SELLER DISCLAIMS ALL WARRANTIES WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

LIMITATION OF SELLER'S LIABILITY

Seller's liability to Buyer for any loss or claim, including liability incurred in connection with (i) breach of any warranty whatsoever, expressed or implied, (ii) a breach of contract, (iii) a negligent act or acts (or negligent failure to act) committed by Seller, or (iv) an act for which strict liability will be inputted to seller, is limited to the "limited warranty" of repair and/or replacement as so stated in our warranty of product. In no event shall the Seller be liable for any special, indirect, consequential or other damages of a like general nature, including, without limitation, loss of profits or production, or loss or expenses of any nature incurred by the buyer or any third party.

UE specifications subject to change without notice.

FOR A LIST OF OUR INTERNATIONAL AND DOMESTIC REGIONAL SALES OFFICES PLEASE VISIT OUR WEBPAGE WWW.UEONLINE.COM



180 Dexter Avenue, P.O. Box 9143 Watertown, MA 02471-9143 USA Telephone: 617 926-1000 Fax: 617 926-2568 http://www.ueonline.com